

ORIFICE AND FREE JET FLOW TRAINER

Model Number: GOTT-OFJFT-01



DESCRIPTION

GOTT-OFJFT-01 is designed to be positioned on the side channels of the hydraulics bench top channel. The inlet pipe should be connected to the bench supply. An adjustable overflow pipe is provided adjacent to the header tank to allow changes in the head. A water tank scale indicates the water level inside the tank. Two orifice plates of differing diameters are provided and may be interchanged by slackening the two thumb nuts. The diameter of the hole that provided is 3mm and 6mm. The trajectory of the jet is plotted using the 8 vertical needles. In operation, main scale is positioned at the back backboard, and the needles are adjusted to follow the profile of the water jet. The needles may be locked using a screw on the mounting bar. The profile may be plotted by marking the main scale at the backboard at the point at where the needle was decrease to follow the water profile.

FEATURES

- Constant head tank with two interchangeable orifices
- Quick release fitting for easy connection to hydraulics bench
- Jet trajectory measured and plotted using adjustable pointers

SPECIFICATIONS

Diameter of small orifice: 0.003m Diameter of large orifice: 0.006m Surface Area of Reservoir: $AR = 0.4713m^{2}$

EXPERIMENT TOPICS

- Determination of Coefficient of Velocity from Jet Trajectory
- Determination of Coefficient of Discharge Under Constant Head
- Determination of Coefficient of Coefficient of Discharge Under Varying Head

Manuals:

- (1) All manuals are written in English
- (2) Model Answer
- (3) Teaching Manuals

General Terms:

- (1) Accessories will be provided where applicable.
- (2) Manual & Training will be provided where applicable.
- (3) Design & specifications are subject to change without notice.
- (4) We reserve the right to discontinue the manufacturing of any product.

Warranty:

2 years

ORDERING INFORMATION:

ITEM	MODEL NUMBER	CODE
ORIFICE AND FREE JET FLOW TRAINER	GOTT-OFJFT-01	200-005